



VIP+ Patient Room Door

VIP+ Patient Room Sliding Door Installation Instructions

Read and Fully Understand These Instructions Prior to Beginning the Installation.

1. When unloading the Doors from the crate, DO NOT Carry or handle the board in the FLAT position. The Door must remain vertical at all times.
2. Locate and pre-drill mounting holes in header to attach track, tight to wall on the closed side. Install track.
NOTE: All screws must be fully countersunk in order for the soft close mechanism to be able to pass.
3. Locate and install guide pin in the floor. Location is CL of the track and 40" from the closed wall. Drill a 3/8" diameter hole in the slab 1 1/16" deep. Set drop-in anchor, insert 1/4"-20 BOL, Rubber sleeve and washer into anchor with Loctite on the threads. Use previously included piece of bottom trim as a guide; tighten bolt until rubber sleeve barely contacts inside of rail. Sleeve will expand as it is tightened.
NOTE: Guide pin must be in the level plain of the track for the door to correctly operate.
4. Attach carriages and soft closing mechanisms to the top of the panel. Slide carriage side first into the top track with the Hex bolts on each side of trim. Center the carriages with the soft closing mechanisms touching in the middle panel. Tighten the jam nut to secure the carriages and soft closing mechanisms.
5. Pull the spring tab to "cock" the soft closing mechanisms.
NOTE: The soft closing mechanisms must be cocked in order for them to engage with the track pin.
6. Remove the outside (open position) soft close engagement pin from the track.
7. Slide the panel into the track and reinstall engagement pin.
8. Push the door to the closed position.
NOTE: The soft close mechanism may require adjustment to stop the door exactly where desired. To adjust the soft close position, loosen the jam nut and slide the carriage and soft close mechanism until the door stops where desired. Re-tighten the jam nut to the panel. Repeat this process on the open side of the track.

VIP+ Patient Room Sliding Door Installation Instructions

Read and Fully Understand These Instructions Prior to Beginning the Installation.

9. Install track end cap.
10. Install the panel end caps on the top and bottom rails on the acrylic (closed) side of the panel. Apply a few small drops of Fuse-It Adhesive (provided) around the end cap and insert into the aluminum extrusion.
11. To install the door pull, run a 1/8" bead of Fuse-It Adhesive (provided) between the pre-drilled holes on both sides of the acrylic panel. Insert the blind tapped handle into the recessed pocket on the Patient Room Side Door, place the countersunk handle on the bathroom side of the door and insert screws through pre-drilled holes.

NOTE: Use a #2 hand screwdriver to install the handle. The screws provided are powder coated to match the handle and if stripped will chip the powder coat. If for any reason the screws bottom out in the handle prior to securing, use the 1 7/8" screws provided.

