Merge Rail 3 Rail Sliding Installation Instructions

Provided:

- a. 1^{1/2}" Aluminum Rail Lengths
- b. Frameless Porcelain Steel Boards
- c. Clip-on Mounting Brackets
- d. Angle Mounting Brackets
- e. Butt Connectors (optional)
- f. 5/16" 18 x 1/2" Button Head Bolts

Tools Needed:

- 1. Laser Level/Level
- 2. Drill
- 3. Provided Install Jigs
- 4. Tape Measure
- 5. 3/4" Flat Head Drywall Screws

Installation:

- Mark a line 1 ¹/₂" below where you would like the top of the system installed, preferably using a laser level.
- Locate the edges of the rail left and right and mark 1/8" beyond on either side. (Figure 1)
- 3. Mark 3/8" above your horizontal line every 3' starting 3' from the edge of the rail. This will be used to locate the clip-on mounting brackets.




Figure 1

Ocoronagroupinc

p. 205.941.1942 · info@coronagroupinc.com · www.coronagroupinc.com

Merge Rail 3 Rail Sliding Installation Instructions

- 4. Align the bottom of the clip-on mounting brackets with the marks from the previous step as shown in (Figure 2) and screw to the wall using ³/₄" flat head drywall screws. The screws must be flat head to allow the rail to clip onto the mounting bracket.
- 5. If the system length is over 240", your rails may need to be spliced together using a butt connector. Position the butt connector in the back slot so that 3 set screws engage each rail. Making sure that the rails are in line with one another, tighten the set screws.
- Verify the end locations by holding up the rail to the wall. Make sure that your marks 1/8" outside are correct.
- 7. Align the angle mounting bracket as shown in (Figure 3) to the line 1/8" from the edge of the rail and screw to the wall using the same ³/₄" flat head drywall screws. The flange with the drywall screws should be covered by the rail after it's installed.




Figure 2




Figure 3 (right side)

Ocoronagroupinc

Merge Rail 3 Rail Sliding Installation Instructions


- 8. Lift the top aluminum rail without the plastic insert, smooth side out, onto the clip-on mounting brackets. The rail should slip onto the bracket with slight downward pressure and be locked in place.
- 9. Take the provided 5/16"-18 x ¹/₂" screws and thread them through the angle mounting brackets into the ends of the aluminum rail.
- Fit the provided install jigs on either end of the middle rail in the same orientation as the top rail. The middle and bottom rails will have a plastic insert that will face upwards. Hang the middle rail from the top using the install jig. (Figure 4)
- 11. Holding the middle rail against the wall, mark where the bottom of the rail lands and remove the rail and install jigs.
- 12. Repeat steps 2-8 to install the middle rail.
- 13. Using the same method to locate the middle rail, locate the bottom rail and repeat steps 2-8 to complete installation.



Figure 4

Ocoronagroupinc

Merge Rail 3 Rail Sliding Installation Instructions



Coronagroupinc

p. 205.941.1942 · info@coronagroupinc.com · www.coronagroupinc.com